IC 915

NTC-PTC/ P R V-I I-V/ Pt100 Tc

double stage electronic controller






Scrolls through the menu items
Increases the values



DOWN Scrolls through the menu





fnc ESC function (quit)



Accesses the Set point and the Menus
Confirms the commands

set

LEDs



Relay OUT 1

ON for relay on (energized);blinking for delay, protection or enabling blocked.



Relay OUT 2

ON for relay on (energized); blinking for delay, protection or enabling blocked.



Alarm


ON for active alarm; blinking for silenced

SETTING THE SET POINT - MACHINE STATUS MENU

Press the 'set' button and release it to access the machine status

In normal conditions, the labels for the two Set point values are found in the menu.

Once the 'SP1' label has been displayed, press the "set" button to display the Set point 1 value.



The Set point 1 value appears on the display. To change the Set point value, use the "UP" and "DOWN" buttons within 15 seconds.

If you press the "set" button again, when the fnc button is pressed or 15 seconds elapse, the last value displayed will be stored and the "SP1" label will reappear on the display.

To set the Set point 2 value, follow the same procedure for setting Set point 1.

PROGRAMMING MENU

To access the Programming menu, hold the "set" button down for more than 5 seconds.





 When the 'set' button is pressed, the first folder in the menu is displayed. (e.g.: "rE1" folder)





 By using the 'UP' e 'DOWN' buttons, you can scroll through all the folders in the programming menu





 By pressing the "set" button for the selected folder (in this example, 'diS') the first parameter is displayed. Use the "UP" and "DOWN" buttons to select the required parameter.

Press "set" to display the selected parameter value and use the "UP" and "DOWN" buttons to change it.

Once the "set" button has been pressed (or the 15 second time out elapses) the new value is stored and the label of the corresponding parameter will be displayed.

PASSWORD

Access to parameter handling can be limited by using a password. The password can be enabled by setting the PA1 parameter in the 'diS' folder. The password is enabled if the value of the PA1 parameter is not 0.





To enter the Programming menu hold the "set" button down for more than 5 seconds.

If specified, the PASSWORD will be requested



 If the PA1 password is enabled (not 0) you will be asked to enter it. Do this by selecting the correct value using the UP and DOWN buttons and confirm by pressing the 'set' button.

If the password is not entered correctly, the device will display the 'PA1' label again and the step will have to be repeated.

COPY CARD

The Copy Card is an accessory connected to the TTL serial port used for quick programming of the unit parameters (upload and download parameter map to one or more units of the same type). upload (UL label), download (dL label) and copy card formatting (Fr label) operations are performed in the following way:





 The 'FPr' folder contains the command needed to use the Copy Card. Press 'set' to access the functions.





 Use the 'UP' e 'DOWN' buttons to display the required function. Press the 'set' to perform uploading (or downloading).





 If the operation is successful 'y' will be displayed, if it is not, 'n' will be displayed.

Download from reset

<u>Connect the copy card when the instrument is OFF</u>. The programming parameters are downloaded when the device is switched on. At the end of the lamp test, the following messages are displayed for about 5 seconds:

- · dLY label if copy operation is successful
- DLn label if operation fails



NOTE:

- After downloading, the instrument will work with the parameter map settings that have just been downloaded.
- see "FPr folder" in Parameter Table and Description of parameters



	ALARMS				
LABEL	Alarm	Cause	Effects	Resolving problems	
E1	Probe 1(control)	 measuring of values outside the nominal reading 	"E1" label appears on display;	check the probe wiring	
	faulty	range	Controller enabled as indicated by the On1 and	 replace the probe 	
		 control probe faulty/shorted/open probe 	OF1 parameters if programmed for the Duty Cycle		

PARAMETER TABLE

	PAR.	RANGE	DEFAULT	U.M.	
	SP1	LS1HS1	0.0	°C/°F	ی ا
	SP2	LS2HS2	0.0	°C/°F	ape
el	HC1	H/C	H/C*	Flag	Display - dIS label
Controller 1-rE1 label	db1	030.0	1*	°C/°F	١١٥
	dF1	030.0	0*	°C/°F	lay
	HS1	LS1HdL	*	°C/°F	isp
	LS1	LdLHS1	*	°C/°F	
	dn1	0250	1	sec	
	dO1	0250	0	min	
	di1	0250	0	min	
	dE1	0250	0	sec	یا ا
	On1	0250	0	min	g
	OF1	0250	1	min	<u> </u>
el	HC2	H/C	H/C*	Flag	Configuration- CnF label
Controller 2-rE2 label	db2	030.0	1*	°C/°F	6
	dF2	030.0	0*	°C/°F	ati
	HS2	LS1HdL	*	°C/°F	<u> 1</u>
	LS2	LdLHS1	*	°C/°F] <u>F</u>
	dn2	0250	1	sec	ၓ
	dO2	0250	0	min	П
	di2	0250	0	min	П
	dE2	0250	0	sec	
	On2	0250	0	min	_
	OF2	0250	1	min	Fpr
NOTE	:c .				\\\\

N	O	TES	:

LOC

- (1) Check the NTC/PTC probe type installed (see label)
- (2) The Pt100 model only works for the Pt100 input (3 wires) whereas Tcj/TcK models, on the basis of this parameter, can work with the Tc input and the Pt100 input.
- (3) If the **Fr** command is used, the data entered in the card will be permanently lost. This operation cannot be undone. After the operation with the Copy Card, the controller must be switched off and then switched back on

Keyboard locked (set point and buttons). However, you can still access

the parameter programming menu and modify parameters including the status of this parameter to allow keyboard unlocking. y = yes; n = no.

	PAR		RANGE	DEFAULT	U.M.
	LOC		n/y	у	flag
Display - dIS label	PA1		0250	0	num
	ndt	IC 915 NTC/PTC	n/y	n	flag
		IC 915 V-I	n/y/int		num
		IC 915 Pt-100	n/y		flag
	CA1	NTC/PTC-Pt100	-30.030.0	0.0	°C/°F
isp		IC 915 V-I			num
Δ	dro	IC 915 NTC/PTC IC 915 Pt100	°C/°F	°C	flag
	LdL	IC 915 V-I	-99.9HdL	0*	°C/°F
	HdL	IC 915 V-I	LdL100	100/100.0/1000	°C/°F
	H00	IC 915 NTC/PTC	(1) PtC/ntC	PtC/ntC*	flag
Configuration- CnF label	(!)	IC 915 V-I	420/020/010/05/01	*	num
		IC 915 Pt100-Tc(2	2) Pt1/JtC/HtC	Pt1/JtC/HtC*	num
	H01		0/1/2	0/1/2*	num
	H03	IC 915 V-I	(ndt=n) -99100 (ndt=y) -99.0100.0 (ndt=int) -9901000	20*	num
	H04	IC 915 V-I	(ndt=n) -99100 (ndt=y) -99.0100.0 (ndt=int) -9901000	*	num
ᆼ	H10		0250	0	min
	rEL		/	/	/
	tAb		/	/	/
	rEL		/	/	/
	UL		/	/	/
_	dL		/	/	/
Fpr	Fr (3)	1	/	/	/
WAF	RNING	(I)			

WARNING(!)

If one or more parameters marked with (!) are modified, the controller must be switched off after the modification and then switched back on **N.B.:** The **dro** parameter is not present in models IC 915 NTC/PTC and Pt100/TcJ-TcK.

The LdL, HdL, H03 and H04 parameters are only present in the IC 915 V-Imodel

be undone. After the operation with the Copy Card, the controller

must be switched off and then switched back on


* The default value depends on the model

Copy Car	a, the controller must be switched off and then switched back on	* Ine	e default value depends on the model
	DESCRIPTION (OF PA	ARAMETERS
	CONTROLLER 1/CONTROLLER 2 (folders with "rE1"/"rE2" label)	PA1	Password 1. When enabled (value is not 0) it represents the access key to
	If set to H, the controller operates in heating mode. If set to C, the controller operates in cooling mode.	ndt	level 1 parameters. number display type. Display with decimal point.
db1/db2 dF1/dF2	Operating band 1, 2 See ON-OFF control diagram Relay 1 intervention differential. The load will stop when Set point 1 is	CA1	y = Yes; n = No.; int=integer Calibration 1. Positive or negative temperature value that is added to the value read by control probe (probe 1) before being displayed or used
HS1/HS2	reached (as indicated by the control probe) and will restart at a temperature equal to Set point 1(2) plus (or minus depending on HC1/HC2) the value of the differential. See ON-OFF control diagram Maximum value for set point 1/2.	LdL HdL	for control. Minimum value the instrument is able to display. Maximum value the instrument is able to display.
LS1/LS2	Minimum value for set point 1/2. CONTROLLER 1 PROTECTIONS/CONTROLLER 2 PROTECTIONS (folders with "rE1"/"rE2" label)	dro	Select °C or °F to display temperature read by probe. N. B.: switching from °C to °F DOES NOT modify set points, differentials, etc. (for example set point=10°C becomes 10°F). CONFIGURATION (folder with "CnF" label)
dn1/dn2 do1/do2	Start-up delay. The specified time must elapse between the controller relay start-up request and actual start-up. Delay after shut-down. The specified time must elapse between shut-	H00 H01	Selection of probe type. Output link. 0 = independent; 1 = dependent; 2 = Neutral Area (or win-
d01/d02	down of the controller 1/2 relay and a subsequent start-up.	H03	dow) Minimum value of current input
di1/di2	Delay between start-ups. Between two subsequent start-ups of the controller 1/2, the specified time must elapse.	H04 H10	Maximum value of current input Output delay from power-on Attention! If $= 0$ is not active; if $\neq 0$ the
dE1/dE2	Shut-down delay. The specified time must elapse between the controller 1/2 relay shut-down request and actual shut-down. NOTE: for parameters dn1, dn2, do1, do2, di1, di2, dE1	rEL tAb	output will not be activated before this time has expired Device version. Read only parameter. Reserved. Read only parameter.
On1/On2	0= not active Controller start-up time if probe is faulty. If set to "1" with Oft at "0" the controller is always on whereas if	UL	COPY CARD (folder with "Fpr" label) UpLoad: transfer of programming parameters from instrument to Copy Card.
OF1/OF2	Oft>0 it operates in duty cycle mode. Controller shut-down time if probe is faulty. If set to "1" with Ont at "0"	dL	downLoad: transfer of programming parameters from Copy Card to instrument.
011/012	the controller is always off whereas if Ont>0 it operates in duty cycle mode. DISPLAY (folder with "dis" label)	Fr	Format. Cancelling all data entered in the copy card. N.B.: If "Fr" parameter (copy card formatting) is used, the data entered in the card will be permanently lost. This operation cannot
	The state of the s		be undered After the eneration with the Conv Card, the controller


IC 915

TECHNICAL DATA	IC 915 NTC/PTC	IC 915 P/R/V-I/I-V	IC 915 Pt100/TC
Front protection	IP65	IP65	IP65
Casing	resin plastic casing PC+ABS UL94 V-0, polycarbonate front polycarbonate front. thermoplastic resin buttons	resin plastic casing PC+ABS UL94 V-0, polycarbonate front polycarbonate front, thermoplastic resin buttons	resin plastic casing PC+ABS UL94 V-0, polycarbonate front polycarbonate front. thermoplastic resin buttons
Dimensions	• front panel 74x32 mm, depth 59mm (terminals excluded)	(pal	front panel 74x32 mm, depth 59mm (terminals excluded)
Mounting	panel-mounted with drilling template 71x29 mm (+0.2/-0.1 mm)		panel-mounted with drilling template 71x29 mm (+0.2/-0.1 mm)
Operating temperature	-5°C55°C	-5°C55°C	-5°C55°C
Storage temperature	-30°C0.85°C	-30°C0.85°C	-30°C0.85°C
Usage ambient humidity humidity	100.90% RH (non-condensing)	100.90% RH (non-condensing)	100.90% RH (non-condensing)
Display range	NTC: -50110°C (-58230°F) / PTC: -50140°C(-58302°F) on display 3 1/2 digits plus sign	2°F) -99100 (ndt=n), -99,9100,0 (ndt=y), -9991000 (ndt=int) on display 3 1/2 digits plus sign	Pt100: -150650°C / TcJ: -40750°C / TcK: -401350°C* on display 3 1/2 digits plus sign
Analogue input	1 NTC or PTC input (parameter selectable)	1 V-I (0-1V, 0-5V, 0-10V, 0-20mA, 420mA par.H00)	
Serial	TTL for Copy Card connection	TTL for Copy Card connection	TTL for Copy Card connection
Digital outputs (configurable) - output OUT1 - output OUT2	1 SPDT 8(3)A 1/2 hp 250 V~ 1 on SPST relav 8(3)A 1/2 hp 250 V~	1 SPDT relay 8(3)A 1/2 hp 250 V~ 1 SPST relay 8(3)A 1/2 hp 250 V~	1 SPST relay 8(3)A 1/2 hp 250 V~ 1 on SPST relay 8(3)A 1/2 hp 250 V~
Buzzer output	only in some models	only in some models	only in some models
Measurement range	from ?50 to 140°C	from -999 to 1000	from -150 to 1350
Accuracy	better than 0.5% of full scale + 1 digit.	better than 0.5% of full scale + 1 digit.	see "Pt100/TcJ/TcK models" table
Resolution	0.1°C (0.1°F up to +199.9°F; 1°F above)	1 or 0.1 digits depending on parameter settings	see "Pt100/TcJ/TcK models" table
Consumption	1.5 W max(mod. 12V) / 3 VA max (mod. 23UV)	1.5 vv max(mod. 12V) / 3 vA max (mod. 23UV)	1.5 W max(mod. 12V) / 3 vA max (mod. 23UV)
Power supply	12/2/=, 12/24 /~/=, 24/2/= 10%, 110/115/~, 220/230 V~ 10% 50/60 Hz	12√-/π, 12/24 √-/π, 24√-/π 10%, 110/115√-, 220/230 V~ 10% 50/60 Hz	12V~/::, 12/24 V~/::, 24V~/:: 10%, 110/115V~, 220/230 V~ 10% 50/60 Hz
Pt100/ TcJ/ TcK MODELS			
41	3 (C) THE CHILD IN		
Accuracy:			IC 915 Pt100/1C - 12 V
0,5% for full scale value + 1 digit;	_		
0.2% from -150 to 300°C	• • • • • • • • • • • • • • • • • • •		
Resolution:	1 2 3 4 5 6 7 8 9 10	1 2 3 4 5 6 7 8 9 10 11	1 2 4 5 6 7 10 11 12
0.1°C (0.1°F) up to 199.9°C; 1°F		+ •	
over TcJ:	Middns	vzi- O NddnS	Aldding
Accuracy:			
0.4% for full scale value + 1 digit;	IC 915 NTC-PTC - 230 V	IC 915 P/R/V-I/I-V - 230 V	IC 915 Pt100/TC - 230 V
Resolution:	OUT1 OUT2	OUT1 OUT2	OUT1 OUT2
Tc (1 F)			
Accuracy:	2	7 2 2 4 5 6 7 1	1011111
0,5% for full scale value + 1 digit;	01 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		7
0.3% from -40 to 800°C	• (Z 1-
Resolution:	Supply	ASIS OF AIGHT	Aidding
	N.O. controller relay OUT1	N.O. controller relay OUT1	N.O. controller relay OLIT1
The technical characteristics in this docu- ment concerning measurements (range.			4-5 N.O. controller relay OUT2
accuracy, resolution, etc.) refer to the			
instrument in the strictest sense and not to		6-7 Power supply	-12
any accessories provided such as probes, for example. This means, for example, that	8-10 Pbi probe input (control) A TTI input for Cony Card	*8-9-11 Voltage Input (8=ground; 9=signal; 11=12V) *8-10-11 Current input (8=ground: 9=signal: 11=12V)	*11-12 TcJ/TcK input
an error introduced by the probe is added		A TTL input for Copy Card	A IIL input for Copy Card
to any error that is typical of the instru- ment.		* depending on model	מבלובוומוונים כון וווסמבו


CONFIGURATION OF EWPA-EWHS PROBES




EWPA 007/030 2 wires / Transduce



EWHS 300/310 3 wires




EWHS 310 4 wires



ON-OFF CONTROL DIAGRAM

HC1	HC2	H01	type of regulation
Н	С	0	independent set points
Н	С	1	dependent set points
-	-	2	Neutral Zone (or window).


NOTE: examples with HC1=H and HC2=C



independent ON-OFF control diagram.

The two outputs regulate as though they are completely independent






dependent ON-OFF control diagram.

The set point 2 SP2 regulates according to SP1





ON-OFF control diagram Neutral Area (or window). NOTE: if dF1 and dF2 are both =0 the outputs are

deactivated when SP1 is reached



ELECTRICAL CONNECTIONS

Caution! Always switch off machine before working on electrical connections. The instrument has screw terminals for connecting electrical cables with a maximum diameter of 2.5 mm² (only one conductor per terminal for power connections): for terminal capacity, see instrument label. The relay contacts are voltage-free. Do not exceed the maximum current allowed. For higher loads, use a suitable contactor. Make sure that the power voltage complies with the device voltage. The sensor has no connection polarity and can be extended using an ordinary bipolar cable (note that extending the probe may affect the electromagnetic compatibility (EMC) of the instrument: special care must be used when wiring). Probe cables, power supply cables and the TTL serial cable should be kept separate from power cables.



Eliwell & Controlli s.r.l.

Via dell'Industria, 15 Zona Industriale Paludi 32010 Pieve d'Alpago (BL) ITALY Telephone +39 0437 986111 Facsimile +39 0437 989066 Internet http://www.eliwell.it

Technical Customer Support:

Telephone +39 0437 986300 Email: techsuppeliwell@invensys.com

Invensys Controls Europe An Invensys Company



cod. 9IS44012 07-05 GB IC 915

MECHANICAL ASSEMBLY

The unit has been designed for panel-mounting. Drill a 29x71 mm hole, insert a tool and fix it in place with the brackets provided. Do not assemble the instrument in excessively humid or dirty locations since it is designed to be used in locations with normal levels of pollution.

Always make sure that the area next to the cooling openings of the tool is adequately ventilated.

RESPONSIBILITY AND RESIDUAL RISKS

Eliwell shall not be liable for any damages deriving from:

- installation/use other than that prescribed and, in particular, which does not comply with the safety standards specified in the regulations and/or those given herein;
- use on boards which do not guarantee proper protection against electric shock, water or dust when assembled:
- use on boards which allow dangerous parts to be accessed without the use of tools;
- tampering with and/or alteration of the product; - installation/use on boards that do not comply with the standards and regulations in force.

DISCLAIMER

This document is exclusive property of Eliwell and cannot be reproduced and circulated unless expressly authorized by Eliwell. Although Eliwell has taken all possible measures to guarantee the accuracy of this document, it declines any responsibility for any damage arising out of its use. The same applies to any person or company involved in preparing and writing this document. Eliwell reserves the right to make any changes or improvements without prior notice and at any time.

CONDITIONS OF USE

PERMITTED USE

For safety reasons the instrument must be installed and used in accordance with the instructions supplied. Users must not be able to access parts with dangerous voltage levels under normal operating conditions.

The device must be suitably protected from water and dust according to the specific application and only be accessible using special tools (except for the front keypad).

The device can be fitted to equipment for household use and/or similar use in the refrigeration sector and has been tested with regard to safety in accordance with the European harmonized reference standards: It is classified as follows:

- as an automatic electronic control device to be integrated as regards its construction;
- as a 1 B type operated control device as regards its automatic operating features;
- as a Class A device in relation to the category and structure of the software.

UNPERMITTED USE

The use of the unit for applications other than those described above is forbidden. It should be noted that the relay contacts supplied with the device are functional and therefore exposed to potential faults. Any protection devices required to comply with product requirements or dictated by common sense due to obvious safety reasons should be installed externally.